



1. Print PDF file
2. Glue to cardboard
3. Cut out hull panels
4. Masking tape together (one half at a time. Then tape the two halves together. use the dashed line to line up)

5. Even up the "top" bow panels and tape together.
6. Then tape the next panels down. (this keeps the hull even)
7. Install the stern panel.
8. Install the bulkhead on the dashed line.
9. Place a thread through the "hole" and hang somewhere.
10. Use a penny taped inside to balance the hull.

